

22. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START

22-1

POOR PERFORMANCE AT HIGH SPEED

22-4

ENGINE LACKS POWER

22-2


POOR HANDLING

22-4


POOR PERFORMANCE AT LOW AND IDLE SPEED


22-3

ENGINE DOES NOT START OR IS HARD TO START




ENGINE LACKS POWER






POOR PERFORMANCE AT LOW AND IDLE SPEED



POOR PERFORMANCE AT HIGH SPEED



POOR HANDLING

