

AIR CLEANER	3-5	FAST IDLE WAX UNIT	5-71
AIR CLEANER HOUSING	5-60	FLYWHEEL INSTALLATION	10-7
ALTERNATOR CHARGING COIL	16-8	FLYWHEEL REMOVAL	10-3
ALTERNATOR COVER INSTALLATION	10-8	FORK	13-14
ALTERNATOR COVER REMOVAL	10-2	FRONT BRAKE CALIPER	15-19
BANK ANGLE SENSOR	5-83	FRONT FENDER	2-15
BATTERY	16-5	FRONT MASTER CYLINDER	15-10
BODY PANEL LOCATIONS	2-0	FRONT WHEEL	13-9
BRAKE FLUID	3-23	FUEL CUT RELAY	5-54
BRAKE FLUID REPLACEMENT/AIR BLEEDING	15-4	FUEL LINE	3-4
BRAKE LIGHT SWITCH	3-25	FUEL LINE INSPECTION	5-50
BRAKE LIGHT SWITCH	19-20	FUEL PUMP	5-53
BRAKE PAD WEAR	3-24	FUEL RESERVE SENSOR	19-18
BRAKE PAD/DISC	15-7	FUEL RESERVE TRIP INDICATOR	21-1
BRAKE PEDAL	15-26	FUEL TANK	5-55
BRAKE SYSTEM	3-24	GEARSHIFT LINKAGE	9-12
CABLE & HARNESS ROUTING	1-23	HANDLEBAR SWITCHES	19-19
CAM CHAIN TENSIONER LIFTER	8-29	HANDLEBARS	13-3
CAMSHAFT INSTALLATION	8-23	HEADLIGHT	19-4
CAMSHAFT REMOVAL	8-6	HEADLIGHT AIM	3-25
CHARGING SYSTEM INSPECTION	16-7	HORN	19-23
CKP SENSOR	17-6	IAT SENSOR	5-80
CLUTCH	9-4	IGNITION SWITCH	19-18
CLUTCH SWITCH	19-21	IGNITION SYSTEM INSPECTION	17-4
CLUTCH SYSTEM	3-26	IGNITION TIMING	17-8
CMP SENSOR	5-81	INJECTOR	5-69
COMBINATION METER	19-8	LICENSE LIGHT	19-8
COOLANT REPLACEMENT	6-4	LOWER COWL	2-6
COOLANT TEMPERATURE GAUGE/SENSOR	19-14	LUBRICATION & SEAL POINTS	1-19
COOLING FAN MOTOR SWITCH	19-16	LUBRICATION SYSTEM DIAGRAM	4-0
COOLING SYSTEM	3-17	MAIN JOURNAL BEARING	12-6
CRANKCASE ASSEMBLY	11-12	MAINTENANCE SCHEDULE	3-3
CRANKCASE SEPARATION	11-3	MAP SENSOR	5-79
CRANKPIN BEARING	12-8	MODEL IDENTIFICATION	1-1
CRANKSHAFT	12-3	MUFFLER/EXHAUST PIPE	2-28
CYLINDER COMPRESSION TEST	8-4	NEUTRAL SWITCH	19-21
CYLINDER HEAD ASSEMBLY	8-19	NUTS, BOLTS, FASTENERS	3-30
CYLINDER HEAD COVER ASSEMBLY	8-27	O ₂ SENSOR (CALIFORNIA TYPE ONLY)	5-88
CYLINDER HEAD COVER DISASSEMBLY	8-5	OIL COOLER	4-8
CYLINDER HEAD COVER INSTALLATION	8-28	OIL PRESSURE INSPECTION	4-3
CYLINDER HEAD COVER REMOVAL	8-4	OIL PRESSURE SWITCH	19-17
CYLINDER HEAD DISASSEMBLY	8-12	OIL PUMP	4-5
CYLINDER HEAD INSPECTION	8-13	OIL STRAINER/PRESSURE RELIEF VALVE	4-3
CYLINDER HEAD INSTALLATION	8-21	PAIR SOLENOID VALVE	5-86
CYLINDER HEAD REMOVAL	8-11	PGM-FI (PROGRAMMED FUEL INJECTION) SYSTEM	5-6
DIODE	18-11	PGM-FI SELF-DIAGNOSIS MALFUNCTION INDICATOR LAMP (MIL) FAILURE CODES	5-10
DRIVE CHAIN	3-19	PILLION SEAT/REAR COWL ('01 - '03)	2-3
ECM (ENGINE CONTROL MODULE)	5-85	PISTON/CYLINDER	12-11
ECT SENSOR	5-80	POOR HANDLING	22-4
EMISSION CONTROL INFORMATION LABEL (U.S.A. ONLY)	1-46	POOR PERFORMANCE AT HIGH SPEED	22-4
EMISSION CONTROL SYSTEMS	1-43	POOR PERFORMANCE AT LOW AND IDLE SPEED	22-3
ENGINE DOES NOT START OR IS HARD TO START	22-1	PURGE CONTROL SOLENOID VALVE (CALIFORNIA TYPE ONLY)	5-87
ENGINE IDLE SPEED	3-17	PRESSURE REGULATOR	5-70
ENGINE INSTALLATION	7-10	RADIATOR	6-8
ENGINE LACKS POWER	22-2	RADIATOR COOLANT	3-17
ENGINE OIL/OIL FILTER	3-14	RADIATOR RESERVE TANK	6-15
ENGINE REMOVAL	7-5	REAR BRAKE CALIPER	15-23
ENGINE STOP RELAY	5-85	REAR COWL (After '03)	2-5
EVAPORATIVE EMISSION CONTROL SYSTEM (CALIFORNIA TYPE ONLY)	3-19		

INDEX

REAR FENDER ('01 - '03)	2-15	SYSTEM TESTING	6-3
REAR FENDER (After '03)	2-18	TACHOMETER	19-14
REAR MASTER CYLINDER	15-15	TAIL/BRAKE LIGHT	19-7
REAR WHEEL	14-3	THERMOSTAT	6-6
REGULATOR/RECTIFIER	16-9	THROTTLE BODY	5-62
RIGHT CRANKCASE COVER INSTALLATION	9-15	THROTTLE OPERATION	3-4
RIGHT CRANKCASE COVER REMOVAL	9-3	TOOLS	1-17
SEAT ('01 - '03)	2-2	TORQUE VALUES	1-12
SEAT (After '03)	2-2	TP SENSOR	5-82
SEAT RAIL ('01 - '03)	2-22	TRANSMISSION	11-6
SEAT RAIL (After '03)	2-25	TROUBLESHOOTING	
SECONDARY AIR SUPPLY SYSTEM	3-18	(ALTERNATOR/STARTER CLUTCH)	10-1
SERVICE INFORMATION		(BATTERY/CHARGING SYSTEM)	16-3
(ALTERNATOR/STARTER CLUTCH)	10-1	(CLUTCH/GEARSHIFT LINKAGE)	9-2
(BATTERY/CHARGING SYSTEM)	16-1	(COOLING SYSTEM)	6-2
(CLUTCH/GEARSHIFT LINKAGE)	9-1	(CRANKCASE/TRANSMISSION)	11-2
(COOLING SYSTEM)	6-1	(CRANKSHAFT/PISTON/CYLINDER)	12-2
(CRANKCASE/TRANSMISSION)	11-1	(CYLINDER HEAD/VALVES)	8-3
(CRANKSHAFT/PISTON/CYLINDER)	12-1	(ELECTRIC STARTER)	18-2
(CYLINDER HEAD/VALVES)	8-1	(FRAME/BODY PANELS/EXHAUST SYSTEM)	2-1
(ELECTRIC STARTER)	18-1	(FRONT WHEEL/SUSPENSION/STEERING)	13-2
(ENGINE REMOVAL/INSTALLATION)	7-2	(FUEL SYSTEM)	5-3
(FRAME/BODY PANELS/EXHAUST SYSTEM)	2-1	(HYDRAULIC BRAKE)	15-3
(FRONT WHEEL/SUSPENSION/STEERING)	13-1	(IGNITION SYSTEM)	17-3
(FUEL SYSTEM)	5-1	(LIGHTS/METERS/SWITCHES)	19-3
(HYDRAULIC BRAKE)	15-2	(LUBRICATION SYSTEM)	4-2
(IGNITION SYSTEM)	17-1	(REAR WHEEL/SUSPENSION)	14-2
(LIGHTS/METERS/SWITCHES)	19-1	TURN SIGNAL	19-6
(LUBRICATION SYSTEM)	4-1	TURN SIGNAL RELAY	19-23
(MAINTENANCE)	3-1	UPPER COWL	2-9
(REAR WHEEL/SUSPENSION)	14-1	VALVE CLEARANCE	3-9
SERVICE RULES	1-1	VALVE GUIDE REPLACEMENT	8-16
SHIFT FORK/SHIFT DRUM	11-4	VALVE SEAT INSPECTION/REFACING	8-17
SHOCK ABSORBER	14-9	WATER PUMP	6-13
SHOCK LINK LOWER BRACKET INSTALLATION	7-16	WHEELS/TIRES	3-30
SHOCK LINK LOWER BRACKET REMOVAL	7-3	WIRING DIAGRAM	20-1
SIDE STAND	3-26		
SIDE STAND SWITCH	19-21		
SPARK PLUG	3-6		
SPECIFICATIONS	1-3		
SPEEDOMETER/VEHICLE SPEED SENSOR	19-12		
STARTER CLUTCH	10-5		
STARTER MOTOR	18-4		
STARTER RELAY SWITCH	18-10		
STARTER VALVE	5-73		
STARTER VALVE SYNCHRONIZATION	5-77		
STATOR	10-2		
STEERING HEAD BEARINGS	3-31		
STEERING STEM	13-24		
SUSPENSION	3-27		
SUSPENSION LINKAGE	14-12		
SWINGARM	14-14		
SYSTEM DIAGRAM			
(BATTERY/CHARGING SYSTEM)	16-0		
(ELECTRIC STARTER)	18-0		
(FUEL SYSTEM)	5-5		
(IGNITION SYSTEM)	17-0		
SYSTEM FLOW PATTERN	6-0		
SYSTEM LOCATION			
(FUEL SYSTEM)	5-4		
(LIGHTS/METERS/SWITCHES)	19-0		